




Ball Placement WITHOUT a Tee

- 1) Place the ball so the green laser is shining on the ball or right next to the ball.**
- 2) The system is ready when the green laser is OFF and you have a “Ready” status.**
- 3) If you’re not getting a “Ready” or the green dot is still on try re-placing the ball and moving the club 1 foot away from the ball until the light goes off and “Ready” status is achieved.**



Ball Placement WITH a Tee

- 1) Use only the approved blue “BirdTees” provided by the club.**
- 2) Place the ball on the tee in front of the green dot, so the ball/Tee is between the green dot and screen.**
- 3) Important: If you experience “ballooning” where the ball flight is extremely high on the sim, make sure you are teeing up the ball IN-FRONT of the green dot like the picture shows.**



****The light switch on the computer stand controls the spotlight, please turn off after your round is over****

Troubleshooting:

- 1) If you experience choppy/slow graphics or frequent freezing please hit the  key and restart the PC.**

Have Fun, please clean up after yourself & text us with any issues

502-609-4301