

Ball Placement

1) Place the ball so the green laser indicator is shining on the ball or right next to the ball.

2) The system is ready when the green indicator laser is OFF and you have a “Ready” status.

3) If the laser indicator does not disappear, bring your club away from the ball for a few seconds and make sure the hitting area is clear of other balls / tees.

IMPORTANT

To wake simulator – Quick press power button on PC



Have Fun, please clean up after yourself & text us with any issues!

502-609-4301

Troubleshooting-

If you experience choppy/slow graphics or frequent freezing please hit the  key and restart the PC.

- Marked up balls or dirty balls WILL cause misreads.

- Dirty bays WILL cause misreads, don't be afraid to vacuum if needed 😊

- Putting issues can occur if you're leaning too far forward over the ball, blocking the sensors. (Turn hat backwards)